




TR-9 Series




TR90




TR91



TR93











TR93



TR95-96

Circuit diagram



Assembly

